FRANKE FILTERFLOW

Valve Change Guide - Zurich



Before you begin

Replacing the valves of a Filterflow tap is a straightforward procedure for any competent handyperson. However, should you have any doubts about your ability to tackle the task we suggest you engage a suitably qualified professional.

Tools required:

- 1. 17mm ring spanner or a suitable adjustable spanner
- 2. Slotted screw driver
- 3. Plumbers grips

The valve change procedure- hot valve

1. Turn off the hot water supply.

2. Remove the index (A) from the centre of the handle by inserting a small flat bladed screwdriver at the edge and carefully prising it out.

- 3. Unscrew and remove the handle retaining screw (B).
- 4. Remove the handle (C).

5. Unscrew the old valve (D) using a 17 mm spanner or a suitable adjustable one. Bear in mind that it might take some initial force to free the valve if it has been in place for some time.

- 6. Screw the valve into its correct location.
- 7. Refit handle (C), tighten screw (B) with the slotted screwdriver and reposition index (A).
- 8. Turn the hot water supply back on and check for leaks.

The valve change procedure- cold/ filtered valve

1. Turn off the cold water supply .

- 2. Remove the index (E) from the centre of the handle by inserting a small flat bladed screwdriver at the edge and carefully prising it out.
- 3. Unscrew and remove the handle retaining screw (F).
- 4. Remove the handle (G).
- 5. Unscrew the collar (H) using plumbers grips.

6. Unscrew the old valve (I) using a 17 mm spanner or a suitable adjustable one. Bear in mind that it might take some initial force to free the valve if it has been in place for some time.

- 7. Screw in the new valve (I) whilst ensuring the raised lug is aligned with the hole within the tap body.
- 8. Tighten the collar (H) and reposition handle (G).
- 9. Tighten screw (F) with the slotted screwdriver and then reposition indice (E).
- 10. Turn the water supply back on and check for leaks.



GRL Direct +44 (0)1603 875468 contact@grldirect.co.uk www.grldirect.co.uk

